

## Chapter 1 : HP PSC All-in-One Printer : User Guide

*Manuals or user guides for your HP Deskjet All-in-One Printer.*

You can also share your printer over an existing Ethernet network using a computer as a print server. Page 15 Chapter 3 printer using printer sharing. The computer directly connected to the HP All-in-One acts as the host for the printer and has full feature functionality. Other computers on the network, which are referred to as clients, have access only to the print features. All other functions must be performed on the host computer. Page 16 4 Load originals and load paper This chapter provides instructions for loading originals on the glass to copy or scan, choosing the best paper type for your job, loading paper in the paper tray, and avoiding paper jams. Load an original You can copy or scan up to letter- or A4-size originals by loading them on the glass, as described here. Note Many of the special features will not work correctly if the glass and lid backing are not clean. Review the following recommendations to get the best printing and copying quality. Whenever you change paper types or sizes, remember to change those settings. Recommended papers If you want the best print quality, HP recommends using HP papers that are specifically designed for the type of project you are printing. Tap a stack of paper on a flat surface to align the edges, and then check the paper for the following: Insert the stack of paper into the paper tray with the short edge forward and the print side down. Slide the stack of paper forward until it stops. Tip If you are using letterhead, insert the top of the page first with the print side down. Page 20 For best results, set the paper type and paper size before copying or printing. Tip To help prevent rips, wrinkles, and curled or bent edges, store all paper flat in a resealable bag. If the paper is not stored properly, extreme changes in temperature and humidity might result in curled paper that does not work well in the HP All-in-One. To load 10 x 15 cm 4 x 6 inch photo paper 1. Remove all paper from the paper tray. Do not use shiny or embossed envelopes or envelopes that have clasps or windows. Note For specific details on how to format text for printing on envelopes, consult the help files in your word processing software. For best results, consider using a label for the return address on envelopes. Locate the gray arrow on the nonprinting side of the paper, and then slide the paper into the paper tray with the arrow side facing up. Insert the film so that the white transparency strip with arrows and the HP logo is on top and is going into the paper tray first. For printing from a software application only. Use paper types that are recommended for your HP All-in-One. For more information, see Choose papers for printing and copying. Load originals and load paper For more information about clearing paper jams, see Paper troubleshooting. It does not support other types of USB devices. If you attach a USB device that is not a compatible digital camera to the camera port, an error message appears on your computer screen. Page 25 Chapter 5 PictBridge™ For more information on printing from a PictBridge-compatible digital camera, see the documentation that came with your camera. If the camera is not PictBridge-compliant or is not in PictBridge mode, the PictBridge icon will blink, and an error icon appears in the number of copies area on the control panel as shown below. When this occurs, an error message appears on your computer monitor if you have the HP All-in-One software installed. Page 26 6 Use the copy features The HP All-in-One allows you to produce high-quality color and black-and-white copies on a variety of paper types. You can enlarge or reduce the size of an original to fit a specific paper size, adjust the copy quality, and make high-quality copies of photos, including borderless copies. This chapter provides instructions for increasing copy speed, enhancing copy quality, setting the number of copies to print, and guidelines for choosing the best paper type for your job. The text is comparable to the quality of the Normal setting, but the graphics might be lower quality. Page 28 Copy a two-page document You can use the HP All-in-One to copy a single- or multiple-page document in color or black and white. In this example, the HP All-in-One is used to copy a two-page black-and-white original. Make a borderless copy of a photo For the best quality when copying a photo, load photo paper in the paper tray and then use the Type button to select Photo Paper. You might also want to use the photo print cartridge for superior print quality. Resize an original to fit onto letter or A4 paper Use the copy features If the image or text on your original fills the entire sheet with no margins, use the Resize to Fit setting to reduce your original and prevent unwanted cropping of the text or images at the edges of the sheet. Tip You can also use Resize to Fit to enlarge a small photo to fit within the printable area of

a full-size page. The instructions vary slightly depending on whether you are printing from a Windows computer or a Mac. Make sure you follow the instructions for your operating system in this chapter.

Page 31 Chapter From the File menu in your software application, choose Page Setup. The Page Setup dialog box appears, allowing you to specify the paper size, orientation, and scaling. Specify the page attributes:

Page 32 Mac users Use the Page Setup and Print dialog boxes to change the settings for your print job. Which dialog box you use depends on which setting you want to change. To change the paper size, orientation, or scaling percentage 1.

## DOWNLOAD PDF HP PSC 1510 MANUAL

### Chapter 2 : HP parts for QA PSC All-In-One Printer

*HP Image Zone software entry point is the HP Director. Regardless, the entry point Regardless, the entry point serves as the launching pad for the HP Image Zone software and services.*

Set up your printer: Follow the illustrations on the setup flyer. Insert the software CD in your computer, and then follow the on-screen instructions. Install the software from: Page 2 Control PanelEnglish1On button: Turns the printer on or off. Stops the current operation. Starts a black-and-white copy job. Acts as a resume button after resolving print problems. Starts a color copy job. Acts as a resume button after resolving print problems. Indicates that there is a paper jam, the printer is out of paper, or some event that requires your attention. Page 3 Basic TroubleshootingIf you are unable to print: Make sure the cable connections are secure. Make sure the printer is powered on. The On button will be lit white. MacMake sure that the printer is set as your default printing device: Check your print queue: Point to or tap the upper-right corner of the screen to open the Charms bar, click the Settings icon, click or tap Control Panel, and then click or tap View devices and printers. This warranty does not cover HP ink products that have been refilled, remanufactured, refurbished, misused, or tampered with. Inserte el CD de software en el equipo y siga las instrucciones que aparecen en pantalla. Enciende o apaga la impresora. Permet de lancer une copie en noir et blanc. Permet de lancer une copie en couleur.

### Chapter 3 : HP® PSC All-in-One Ink Cartridges

*Read and download HP All in One Printer PSC All-in-One Printer User's Manual online. Download free HP user manuals, owners manuals, instructions, warranties and installation guides, etc.*

### Chapter 4 : HP All-In-One Inkjet Printer | eBay

*Hp PSC Pdf User Manuals. View online or download Hp PSC User Manual.*

### Chapter 5 : HP Technical Support, Help, and Troubleshooting | HP® Customer Support

*View and Download HP PSC setup manual online. All-in-One series. PSC All in One Printer pdf manual download. Also for: Psc , Psc , Psc s, Psc v, Psc xi, Psc , Psc s, - psc all-in-one color inkjet, Psc*

### Chapter 6 : SOLVED: Hp psc won't print - Fixya

*Get HP HP PSC All-in-One Printer User Guide. Get all HP manuals! ManualShelf. Sign Up. Sign up to create an account Facebook Twitter. or. By clicking Create.*

### Chapter 7 : HP PSC SETUP MANUAL Pdf Download.

*In the Help View er window, choose HP Deskjet series from the Mac Help pop-up menu. Readme: Con tains HP support information, o perating syst em requir ements, and rec ent print er updates.*

### Chapter 8 : HP Deskjet All-in-One Printer : Reference Guide

*select All Programs, click HP, click HP Deskjet series, and then click HP Deskjet series. 2. In the printer software, select Print & Scan, and then click.*

### Chapter 9 : HP Deskjet All-in-One Printer User Guides | HP® Customer Support

## DOWNLOAD PDF HP PSC 1510 MANUAL

*Save on our amazing HP® PSC All-in-One Ink Cartridges with Free Shipping when you buy now online. Get our best deals when you shop direct with HP®.*