

## Chapter 1 : TOMTOM START 20 SERIES REFERENCE MANUAL Pdf Download.

*View a manual of the TomTom Start 25 below. All manuals on calendrierdelascience.com can be viewed completely free of charge. By using the 'Select a language' button, you can choose the language of the manual you want to view.*

See the printed installation poster included with your product for more information. To install your device, do the following: Make sure that both the integrated mount and your windscreen are clean and dry. Plug the USB car charger into the power supply on your dashboard. Press the suction cup of the mount firmly against the windscreen on an area where the glass is flat. Place the integrated mount so that it does not interfere with your view of the road or of any of the controls in your car. Twist the rubber grip near the base of the mount in a clockwise direction until you hear a click. Your navigation device is now installed. The next step is to switch it on and answer a few set-up questions. The first time you switch on your device, you have to hold the button down for up to 15 seconds. Take care to select the correct language as the language you choose will be used for all text on the screen. When you first switch on your device, you have to answer a few questions to set up the device. Answer the questions by tapping the screen.

**GPS reception** When you first start your TomTom Start navigation device, the device may need a few minutes to determine your GPS position and show your current position on the map. In future, your position will be found much faster, usually within a few seconds. To ensure good GPS reception, you should use your device outdoors. Large objects such as tall buildings can sometimes interfere with reception.

**Read me first Page:** It is a good idea to frequently connect your navigation device to MyTomTom to ensure you always have the latest updates. We recommend using a broadband internet connection whenever you connect your navigation device to MyTomTom. Connect your computer to the internet. Start a browser and go to [tomtom.com](http://tomtom.com). Your browser downloads the MyTomTom support application, which you need to install on your computer in order to connect your device to MyTomTom. Follow the instructions on the screen if you are asked questions while downloading. When prompted, connect your device to your computer using the USB cable. Then switch your device on. Once the MyTomTom support application is installed, you can access MyTomTom from the notification area on your desktop. When you connect your navigation device to your computer, MyTomTom tells you if there are any updates for your device. First, check that the battery is charged. To charge the battery, connect your device to the car charger. It can take up to 2 hours to fully charge the battery. If this does not solve the problem, you can reset the device.

**Charging your device** The battery in your TomTom Start navigation device charges when you connect it to the car charger or to your computer. Take care of your navigation device Never leave your TomTom Start or accessories on view when you leave the car as they may become an easy target for thieves. It is important to take care of your device: Extended exposure to sunlight may lead to early deterioration in battery performance. Doing so may be dangerous and will invalidate the warranty. Do not use any liquid cleaners. The mount should not block or interfere with any of the following: You can attach the mount to the windscreen or side window or you can use a Dashboard Mount Disk to attach the mount to your dashboard. The following diagrams show where you can safely attach the mount. TomTom also offers alternative mounting solutions for your TomTom navigation device. For more information about Dashboard Mount Disks and alternative mounting solutions, go to [tomtom.com](http://tomtom.com).

**Safety settings** We recommend using the safety settings to make your driving as safe as possible. These are some of the options included in the safety settings: In the interest of safety and to reduce distractions while you are driving, you should always plan a route before you start driving. To plan a route on your TomTom Start, do the following: Tap the screen to open the Main menu. Tap **Navigate to** or **Drive to**. You can change the country or state setting by tapping the flag before you select a city. Enter the town or city name. Towns with similar names are shown in the list while you type. When the correct city or town appears in the list, tap the name to select the destination. Streets with similar names are shown in the list while you type.

**Planning a route Page:** Enter the house number, then tap **Done**. The location is shown on the map. Tap **Select** to continue or tap **Back** to enter another address. If you want your final destination to be a car park, tap **Car park** and select a location from the list of car parks close to your general destination. When the new route is shown, tap **Done**. For more information about the route, tap **Details**. Your

TomTom Start starts to guide you to your destination, using spoken instructions and on-screen directions.

**Route summary** The route summary shows an overview of your route, the remaining distance to your destination and the remaining estimated journey time. To view the route summary, tap the right-hand panel on the status bar in the Driving view or tap View route in the Main menu and then tap Show route summary. To do this, tap Settings followed by Planning settings and then tap Ask me every time I plan. The types of route you can choose from are as follows: This may not be the quickest route, especially if the shortest route is through a town or city.

**Frequent destinations** If you often make trips to the same destinations, you can set your TomTom Start to ask if you want to plan a route to one of these locations every time the device starts. This is faster than planning a route in the normal way. To select a new destination, tap Start-up settings in the Settings menu and select Ask for a destination. Select a button to use for this destination and answer the questions about the destination. To change this setting, do the following: Tap Start-up settings in the Settings menu and then select Ask for a destination. Tap Yes, then tap Yes again to begin entering information about the destination. Select a symbol for the destination and tap Done to set the symbol, then tap Yes. To add new destinations, select one of the numbered symbols and enter a name for the new destination button. Tap Yes and if required enter a new name, then tap Done. Enter the address details in the same way you enter an address when planning a route, then tap Done. If you want to set more destinations, repeat the steps above. You are asked if you want to change the start-up image. If you want to change the image, tap Yes then follow the instructions shown on the screen. Every time your TomTom Start starts, you are asked if you want to plan a route. If you tap Cancel, you are shown the Main Menu.

**Using arrival times** When you plan a route, your TomTom Start asks you if you need to arrive at a particular time. Tap YES to enter a preferred arrival time. Your Start calculates your arrival time and shows you whether you will arrive on time. You can also use this information to work out when you need to leave. If your Start shows that you will arrive 30 minutes early, you can wait and leave in 30 minutes time, rather than arrive early. Your arrival time is constantly recalculated during your journey. The status bar shows whether you will arrive on time or if you are going to be late, as shown below: You will arrive 55 minutes before the arrival time you entered. If the estimated arrival time is more than five minutes before the time you entered, it is shown in green. You will arrive 3 minutes before the arrival time you entered. If the estimated arrival time is less than 5 minutes before the time you entered, it is shown in yellow. If the estimated arrival time is later than the time you entered, it is shown in red.

**Status bar settings** Tap Status bar settings in the Settings menu, to enable or disable arrival time notifications. To enable arrival time notifications, select Leeway.

**Navigation menu options** When you tap Navigate to or Drive to, you can set your destination in many ways, not just by entering the address. The other options are listed below:

## Chapter 2 : TomTom Start 25

*Tomtom Start 25 PDF manuals for download. Tomtom Start 25 have 23 PDF manuals in 23 languages mainly including Reference Guide.*

Table of Contents Page: If you want a quick read of the essentials, we recommend that you read the Read me first chapter. This covers installation, switching on, setting up and updating using MyDrive. After that, you will probably want to look at route planning and you can read all about that in the Planning a route chapter. For information about what you see on the device itself, go to: There are also frequently asked questions FAQs at tomtom. Select your product model from the list or enter a search term. We hope you enjoy reading about and, most importantly, using your new navigation device! Welcome to navigation with TomTom Page: Disks are included in some products and are available as accessories for others. For more information, go to tomtom. The navigation device should not block or interfere with any of the following: You can attach the device to the windscreen or you can use a Dashboard Mount Disk to attach the mount to your dashboard. Dashboard Mount Disks are included with some products and are available as accessories. The following diagrams show where you can safely attach the mount. TomTom also offers alternative mounting solutions for your TomTom navigation device. For more information about Dashboard Mount Disks and alternative mounting solutions, go to tomtom. Installing in your car Use the mount provided with your device to install your TomTom device in your vehicle. You can attach your device to your windscreen or use a Dashboard Mount Disk to attach your device to your dashboard. See the printed installation instructions included with your product for more information. Read the instructions about positioning your device before you install your device. To install your device, do the following: Choose the best location to mount your TomTom device. The location should be as smooth as possible. If you are using the Dashboard Mounting Disk, clean the dashboard and install the disk. Make sure that both the suction cup on the mount and your windscreen or disk are clean and dry. Press the suction cup of the mount firmly against your windscreen or disk. Turn the rubber grip near the base of the mount in a clockwise direction until you feel it lock. If your mount is not integrated into your device, place your device in the mount, making sure that it clicks into place. Read me first Page: Plug the USB car charger into the power supply on your dashboard. Connect the USB cable to the car charger and your device. Your navigation device is now installed. The next step is to switch it on and answer a few questions. The first time you switch on your device, you have to hold the button down for up to 15 seconds. Take care to select the correct language as the language you choose will be used for all text on the screen. When you first switch on your device, you have to answer a few questions to set up the device. Answer the questions by tapping the screen. GPS reception When you first start your TomTom navigation device, the device may need a few minutes to determine your GPS position and show your current position on the map. In future, your position will be found much faster, usually within a few seconds. To ensure good GPS reception, you should use your device outdoors and keep your device upright. Large objects such as tall buildings can sometimes interfere with reception. GPS reception can also be affected if the device is placed flat on a surface or held flat in your hand. Micro-SD card slot Some types of TomTom navigation devices have a micro-SD card slot that is located on the side or on the bottom of the device. Before you use the memory card slot, make sure that you have the latest version of the application installed on your navigation device by connecting to MyDrive. When your device is up-to-date, you can use a memory card as extra storage space to add extra maps to your device. Maps can be purchased from tomtom. About MyDrive MyDrive is a web-based tool that helps you manage the contents and services of your TomTom navigation device. You use MyDrive to get map updates as well as lots of other things. You log in to MyDrive on the TomTom website. It is a good idea to frequently connect your navigation device to MyDrive to ensure you always have the latest updates. We recommend using a broadband internet connection whenever you connect your navigation device to MyDrive. On your computer, open a web browser and go to tomtom. Click Download MyDrive Connect. Follow the instructions on the screen. When prompted, connect your device to your computer using the USB cable supplied with your device, then switch your device on. Other USB cables may not work. Enter the requested information for account creation,

including your country. When set-up is complete, a MyTomTom account is created and your navigation device is linked to that account. You can now access MyDrive Connect from the notification area on your desktop. MyDrive starts automatically after the account is created. Next time you want to access MyDrive, go to tomtom. When you connect your navigation device to your computer, MyDrive Connect tells you if there are any updates for your device.

**Safety settings** We recommend using the safety settings to make your driving as safe as possible. These are some of the options included in the safety settings: First, check that the battery is charged. To charge the battery, connect your device to the car charger. It can take up to 2 hours to fully charge the battery. If this does not solve the problem, you can reset the device. This can take 30 seconds or more.

**Charging your device** The battery in your TomTom navigation device charges when you connect it to the car charger or to your computer.

**Sharing information with TomTom** When you first start navigating or perform a reset, your device asks for permission to collect some information about your use of the navigation device. The information is stored on the device until we retrieve it. We use it anonymously to improve our products and services. You can change whether you share this information with us at any time by doing the following: In the Main Menu, tap Settings. Tap Me and my device. Tap No to stop sharing or tap Yes to start sharing. For more information, see our privacy policy at tomtom.

**Interference with these devices may endanger the health or life of you or others.** Take care of your navigation device It is important to take care of your device: Doing so may be dangerous and will invalidate the warranty. Do not use any liquid cleaners. For warranty information, go to tomtom.

In the interest of safety and to reduce distractions while you are driving, you should always plan a route before you start driving. If you are using a TomTom camper and caravan product, before planning a route you should set up your device for your vehicle. To plan a route on your TomTom device, do the following: Tap the screen to open the Main Menu. Tap Navigate to or Drive to. You can change the country or state setting by tapping the flag before you select a city. Enter the town or city name, or the postcode. If your device supports voice control, instead of typing the address, tap the microphone button to enter the address by speaking to your TomTom device. Towns with similar names are shown in the list while you type. When the correct city or town appears in the list, tap the name to select the destination.

**Planning a route Page:** Enter the street name. Streets with similar names are shown in the list while you type. When the correct street name appears in the list, tap the name to select the destination. Enter the house number, then tap Done.

## Chapter 3 : Sat Nav | TomTom

1. Getting started 2 Getting started Mounting your navigation device 1. Push the EasyPort™ Mount on your TomTom Start against the windscreen in your car.

Safety Dashboard Mount Disk to attach the mount to your dashboard. The following diagrams show where you can safely attach the mount. TomTom also offers alternative mounting solutions for your TomTom navigation device. For more information about Dashboard Mount Disks and alternative mounting solutions, go to [tomtom.com](http://tomtom.com).

**Planning A Route Important:** In the interest of safety and to reduce distractions while you are driving, you should always plan a route before you start driving. To plan a route on your TomTom Start, do the following: Tap the screen to open the Main menu. Page 12 When the correct street name appears in the list, tap the name to select the destination. Enter the house number, then tap Done. The location is shown on the map. Tap Select to continue or tap Back to enter another address. **Route Summary** To view the route summary, tap the right-hand panel on the status bar in the Driving view or tap View route in the Main menu and then tap Show route summary. **Selecting A Route Type Frequent destinations** If you often make trips to the same destinations, you can set your TomTom Start to ask if you want to plan a route to one of these locations every time the device starts. This is faster than planning a route in the normal way. **Show My Frequent Destinations** Show my frequent destinations You can set your TomTom Start to ask if you want to plan a route to one of your frequently visited destinations every time the device starts. To change this setting, do the following: Tap Start-up settings in the Settings menu and then select Ask for a destination. **Navigation Menu Options** You will arrive 19 minutes late. If the estimated arrival time is later than the time you entered, it is shown in red. Tap Status bar settings in the Settings menu, to enable or disable arrival time notifications. To enable arrival time notifications, select Leeway. **Status bar settings** Navigation menu options When you tap Navigate to or Drive to, you can set your destination in many ways, not just by **Planning A Route In Advance** **Position of last stop** Planning a route in advance You can use your TomTom Start to plan a route in advance, selecting your starting point and your destination. Here are some more reasons to plan a route in advance: Find out how long a journey is going to take before you start. This is useful to see how long a journey takes at different times of the day or on different days of the week. Your TomTom Start plans the route between the two locations you selected. **Viewing route information** You can access these options for the route you last planned by tapping View route in the Main Menu or the Details button on the route summary screen. **Traffic information** is not available in all countries or regions. For more information about Show traffic on TomTom traffic information services, go to [tomtom.com](http://tomtom.com). Tap the centre of the screen at any time to open the Main Menu. The name of the street you are on. **Navigation instruction** for the road ahead and the distance to next instruction. If the second instruction is less than m after the first instruction, you see it shown immediately instead of the distance. **Advanced Lane Guidance** About lane guidance Note: Lane guidance is not available for all junctions or in all countries. Your TomTom Start helps you prepare for motorway exits and junctions by showing the correct driving lane for your planned route. As you approach an exit or junction, the lane you need is shown on the screen. **Changing Your Route** Changing your route Making changes to your route After you plan a route, you may want to change the route or even the destination. There are various ways to change your route without the need to completely replan the entire journey. To change the current route, tap Change route in the Main menu: Tap this button to change the current route. For more information about TomTom traffic information services, go to [tomtom.com](http://tomtom.com). Tap this button to change the current destination. When you change the destination, you are shown the same options and asked to enter the new address in the same way as when you plan a new route. To use a TomTom traffic information service, you may need a subscription or a receiver. Traffic services are not supported in all countries. For more information and to subscribe, visit [tomtom.com](http://tomtom.com). Traffic services are not supported in all countries or regions. **Cursor Menu** Tap this button to make a map correction for the cursor position on the map. You can make the correction only on your own map or you can share the correction with the TomTom Map Share community. **Correct location** Tap this button to create a Favourite at the cursor position on the map.

### Chapter 4 : Start 25 | TomTom Forum and Community

*Find all information about TomTom Start Check out the maps and services we offer for your device, or get access to support. Learn more.*

Getting Started Get-ting started 1. Adjust the angle of your device. Lock the EasyPort Mount by twisting the base. Insert the Car Charger into your device. Gps Reception The Mount comes off of the windshield. In the future, your position will be found much faster, usually within a few seconds. Page 4 First, check that the battery is properly charged. To charge the battery, connect your device to the car charger. It can take up to 2 hours to fully charge the battery. If this does not solve the problem, you can reset the device. First turn your device off and wait for at least 10 seconds. The name of the next street or street sign information. Your speed and the speed limit, if known. Tap this area to repeat the last spoken instruction and to change the volume. Advanced Lane Guidance Note: Lane guidance is not available for all junctions or in all countries. As you approach an exit or junction, the lane you need is shown on the screen. To open the Main Menu from the Driving View, tap the center of the screen. To return to the Driving View from the Main Menu, tap done. Main Menu buttons The following buttons are shown on the Main Menu. This is useful when driving at night or in dark environments such as long tunnels. Tap this button to set the day color scheme, which increases the brightness of the screen and shows the map using bright colors. Browse Map Browse map To look at the map in the same way as you might look at a traditional paper map, tap Browse Browse map in the Main Menu. You can move the map by touching the screen and sliding your finger across the screen. Planning A Route You can enter an address in various ways, but we will enter the full address. Start to type the name of the town where your trip will begin and tap on the name when it appears in the list. Enter the street name and the house number, then tap Done. Before you start to enter a street name, City center is shown at the top of the list. This is useful if you do not have an address and only need general directions. Finding Alternative Routes You then have to choose how much of the route ahead you want to avoid. Avoid roadblock Choose from the different options. Page 13 So you can select from all the same options, for example: Address, Favorite, Point of Interest and Point on map. Change Voice Set clock Tap this button to select the time format and to set the time. The easiest way to set the time is by tapping the Sync button. You can only use Sync if you have GPS reception, so you cannot set the clock in this way when you are indoors. Change Language Tap this button to make a correction to your map. Set units Tap this button to set the units used for the following measurements: Keyboard Preferences Tap this button to change the map you are using. All your settings, including your Home location and any Favorites, are deleted. About Favorites You can then select the location of the Favorite from the list below. You can type your own name for the Favorite when the keyboard is shown. You can set your Home location as a Favorite. Does it make sense to do this? To add a POI as a Favorite, tap this button, then do the following: Deleting A Favorite Changing the name of a Favorite 1. Tap the screen to bring up the main menu. Tap options to open the Options menu. Tap Home and Favorites. Tap the Favorite you want to rename. Here are some examples: Page 21 Tap the arrow to choose from the complete list of categories. Select the category from the list or start to type the name of the category and select it when it appears in the list. Sound And Volume Control Set day color scheme Tap day in the Main Menu to increase the brightness of the screen and show lighter colors on the map. Set day color scheme Set night color scheme Tap night in the Main Menu to reduce the brightness of the screen and show darker colors on the map.

### Chapter 5 : TomTom Start 25 Specs - CNET

*On this page you find the TomTom Start 25 manual. Please read the instructions in this operator manual carefully before using the calendrierdelascience.com you have any questions about your Navigator that are not answered in the manual, please share your question in the troubleshooting section on the bottom of this page.*

### Chapter 6 : Tomtom Start 25 PDF manuals for download - Devicemanuals

## DOWNLOAD PDF TOMTOM START 25 MANUAL

*In rare cases, your TomTom device may not start correctly or may stop responding to your taps. First, check that the battery is charged. To charge the battery, connect your TomTom device to the.*

### Chapter 7 : TOMTOM START USER MANUAL Pdf Download.

*View a manual of the TomTom Start 25 EUROPA below. All manuals on calendrierdelascience.com can be viewed completely free of charge. By using the 'Select a language' button, you can choose the language of the manual you want to view.*

### Chapter 8 : Tomtom Start 25 Instruction Manual

*Manual & Guides - Product User Manuals & Troubleshooting Guides. Products and names mentioned are the property of their respective owners.*

### Chapter 9 : Start 20 user Manual | TomTom Forum and Community

*GPS reception When you first start your TomTom START navigation device, the device may need a few minutes to determine your GPS position and show your current position on the map. In the future, your position will be found much faster, usually within a few seconds.*