

Chapter 1 : Xerox WorkCentre Parts and Service Manual

Product documentation for WorkCentre ///

Depending on the configuration of the machine, some User Interface screens may vary. The data saved in the hard disk of the machine may be lost if there is any problem in the hard disk. Xerox is not responsible for any direct and indirect damages arising from or caused by such data loss. Xerox is not responsible for any breakdown of machines due to infection of computer virus or computer hacking. Important 1 This manual is copyrighted with all rights reserved. Under the copyright laws, this manual may not be copied or modified in whole or part, without the written consent of the publisher. Unauthorised operation can cause faults or accidents. Xerox is not liable for any problems resulting from unauthorised operation of the equipment. Xerox and Ethernet are registered trademarks. Touch Screen The touch screen allows you to select all the available programming features. It also displays fault clearance procedures and general machine information. Services Button Displays the job features on the touch screen. Job Status Button Displays job progress information on the touch screen. Machine Status Button Displays the current status of the machine on the touch screen. Dial Pause Enters a pause in a telephone number when transmitting a fax. Language Changes text to an alternative language when available. Pound Indicates the dialing character or designates a group dial number. Interrupt Temporarily stops the current copy job to allow a priority job to be run. Clear Deletes numeric values or the last digit entered. Start Starts the job. Stop Temporarily stops the current job. Follow the message to cancel or resume your job. Clear All If pressed once, resets the default settings and displays the first screen for the current pathway. If pressed twice, resets all the features to their machine default settings. The bypass tray and trays 1 and 2 are fully adjustable trays and can hold a variety of paper sizes. Trays 3 and 4 are high capacity feeders holding 8. When a paper tray is opened, your machine assumes that more paper is to be loaded. Depending on the machine setup, the touch screen displays a pop-up window, giving the option to change the paper and its attributes, or load more of the same paper. Before loading paper into the paper trays, fan the edges. This procedure separates any sheets of paper that are stuck together and reduces the possibility of paper jams. If the tray information is correct select the Confirm button. Alternatively change the paper size or paper type by selecting the Change Settings button on the touch screen. That completes the procedure for loading the paper tray. When Booklet creation is switched on, you need to tell the machine that your originals are 1-sided or 2-sided. When you have made your selection you must select Save so that you can program any other features you may require from the control panel. The Booklet Creation feature enables the production of booklets or multi-page copies from 1 or 2-sided originals. The machine will scan your originals and automatically reduce and arrange the images in the correct sequence on your selected copy paper so that a booklet is created when the copy set is folded in half. First select the tray that contains the paper you want to use. Always load your documents with the long edge to the left. Information on both sides of the ID Card can be copied onto one side of one sheet of paper, without the need to reload the paper into the paper or bypass tray. Select the All Services icon, then select the Copy icon. Gently lower the Document Feeder. Use the number keypad to enter the number of copies you require. Press Start to begin scanning side 1. Press Start to begin scanning side 2. Printing begins and copies are delivered into the Output Tray. Select Fax as Job Type 2. Enter the Recipient Details 3. Send the Fax 5. When you have selected all the options you require, select OK. The Fax Confirmation screen will appear with the list of recipients you have chosen. If the details are correct, select the OK button and your fax will be submitted to the machine fax queue ready to be transmitted. Thumbnail Preview is an optional feature and may not be available on your machine. Contact your system administrator to set up this feature on your machine. Select the Mailbox Name. Select the Document Name. Select the Send from Mailbox icon. To use this option, the user must first enter their Network Authentication login at the device. The device displays one Scan to Home template. When a document is scanned, the authentication server produces the information as to who is logged in at the device. The system administrator enables the feature using Internet Services. They also have to enable Network Authentication for this feature to be available. Users will then be required to enter the User ID setup with their account to perform certain

DOWNLOAD PDF XEROX WORKCENTRE 7335 SERVICE MANUAL

machine functions. You can create up to accounts. All user accounts must have the following defined: Select the Close button. The printer properties dialogue window will vary according to the driver you are using and the user interface selected. The major features and options will be available on all drivers but there are some differences. Open the Print Driver 1. Choose Enabled if you want a Banner Sheet to be provided with each print job. The meters vary depending on your machine configuration and setup. To access the Billing Meters: Select the Machine Status button. The Billing Meters are displayed. Select the Billing Information tab. The machine will tell you when you will need to order a new cartridge and when to install it. Follow the disposal instructions for the old cartridge when 1. Open the Front Door. Turn the toner cartridge counter clockwise to the unlocked position. Remove the toner cartridge by pulling it straight out. Be careful to not get toner on clothing. Dispose the toner cartridge as normal office waste or recycle the cartridge. Remove the new toner cartridge from its packaging. Shake the new toner cartridge several times in an up and down twisting motion to redistribute the toner. Install the toner cartridge by aligning the arrows on the cartridge with unlock symbol on the printer. Make sure the cartridge is fully installed then turn the cartridge clockwise to the locked position. Close the Front Door. If the door will not close completely, make sure the cartridge is in the lock position and the toner cartridge is installed into the appropriate toner location. That completes the procedure for replacing the toner cartridge. Perhaps the users of ManualsCat. The more precies your question is, the higher the chances of quickly receiving an answer from another user. You will automatically be sent an e-mail to inform you when someone has reacted to your question.

Chapter 2 : XEROX WORKCENTRE SYSTEM ADMINISTRATOR MANUAL Pdf Download.

Xerox WorkCentre Manuals Manuals and User Guides for Xerox WorkCentre We have 8 Xerox WorkCentre manuals available for free PDF download: User Manual, System Administrator Manual, Quick Use Manual, Setup Manual, Quick Network Setup Manual, Brochure & Specs, Copying Manual.

Chapter 3 : Xerox service manual - Fixya

We are asked all the time for a Xerox® Workcentre® service manual in PDF format. As far as we are aware this is only available via the PWS software. You can see all of our Xerox® WorkCentre®, stock by clicking this link.

Chapter 4 : Xerox WorkCentre user manual - calendrierdelascience.com - Solve your problem

If the Media Card Reader is installed on the WorkCentre //, image data (Exif) taken by digital cameras and document files (PDF, TIFF) can be printed by the WorkCentre // For further information, refer to the Media Card Reader User Guide.

Chapter 5 : service manual for a Xerox workcentre 73xx series

Links. Xerox WorkCentre Parts and Service calendrierdelascience.com

Chapter 6 : Xerox WorkCentre Manuals

Xerox service manual - Office Equipment & Supplies Our xerox workcenter fault code and copy service is disabled I have a xerox workcentre.

Chapter 7 : Xerox service manuals and repair manuals

Service Manual & Parts List Xerox WorkCentre WorkCentre WorkCentre WorkCentre WorkCentre WorkCentre WorkCentre ; This manual is in the PDF format and have detailed Diagrams, pictures and full procedures to diagnose

DOWNLOAD PDF XEROX WORKCENTRE 7335 SERVICE MANUAL

and repair your Xerox WorkCentre copier.

Chapter 8 : Xerox WorkCentre RPX manual

I am looking for two free service manuals 1) Xerox workcentre // 2) Xerox Workcentre / Thank You for the Help.

Chapter 9 : XEROX WORKCENTRE ADMIN GUIDE service manual | calendrierdelascience.com

xerox service manual Thu, 01 Nov GMT xerox service manual pdf - Effective May , this product will require the use of a device.